

```
1 SERVER_REC_DB_SERVICE_NAME=server_rec_db
2 SERVER_REC_DB_CONTAINER_NAME=dimis-server-db-
  container
3 DB_NAME=server-db
4 POSTGRES_USER=dimis_dbuser
5 POSTGRES_PASSWORD=dimis_dbpassword
6 SERVER_REC_DB_VOLUME=server_rec_db-volume
7 SERVER_REC_PORT_DOCKER=5432
8 SERVER_REC_PORT_EXT=4321
9 CONSUMER_CONTAINER_NAME=server_consumer
10 RABBIT_HOST=servermq-container
11 RABBIT_USER=rabbitmq
12 RABBIT_PASSWORD=rabbitmq
13 RABBIT_PORT=5672
14 ADMINER_WEB_PORT_DOCKER=8181
15 ADMINER_WEB_PORT_EXT=8182
16 NETWORK_NAME=server-mttq-net
```

```
1  version: '3.8'
2  services:
3    server_rec_db:
4      image: "postgres:11"
5      container_name: "${SERVER_REC_DB_CONTAINER_NAME}"
6      restart: always
7      environment:
8        - POSTGRES_USER=${POSTGRES_USER}
9        - POSTGRES_PASSWORD=${POSTGRES_PASSWORD}
10       - POSTGRES_DB=${DB_NAME}
11     ports:
12       - "${SERVER_REC_PORT_EXT}:${SERVER_REC_PORT_DOCKER}"
13
14     server_consumer:
15       build: .
16       container_name: "${CONSUMER_CONTAINER_NAME}"
17       depends_on:
18         - ${SERVER_REC_DB_SERVICE_NAME}
19       restart: always
20       command: ["/wait-for-it.sh", "${SERVER_REC_DB_CONTAINER_NAME}:${SERVER_REC_PORT_DOCKER}", "--", "python3", "-u", "./pika_consumer.py"]
21     environment:
22       - DB_SERVICE_NAME=${SERVER_REC_DB_SERVICE_NAME}
23       - DB_CONTAINER_NAME=${SERVER_REC_DB_CONTAINER_NAME}
24       - DB_NAME=${DB_NAME}
25       - POSTGRES_USER=${POSTGRES_USER}
26       - POSTGRES_PASSWORD=${POSTGRES_PASSWORD}
27       - RABBIT_HOST=${RABBIT_HOST}
28       - RABBIT_USER=${RABBIT_USER}
29       - RABBIT_PASSWORD=${RABBIT_PASSWORD}
30       - RABBIT_PORT=${RABBIT_PORT}
31
32     server_adminer:
33       image: adminer
34       restart: always
35       environment:
36       - ADMINER_DEFAULT_SERVER=${
```

```
36 SERVER_REC_DB_CONTAINER_NAME}:${{
  SERVER_REC_PORT_DOCKER}
37     - ADMINER_DEFAULT_USER=${{POSTGRES_USER}}
38     - ADMINER_DEFAULT_PASSWORD=${{POSTGRES_PASSWORD}}
39     ports:
40     - "${{ADMINER_WEB_PORT_EXT}}:${{
  ADMINER_WEB_PORT_DOCKER}}"
41     command:
42     - 'php'
43     - '-S'
44     - '[::]:${{ADMINER_WEB_PORT_EXT}}'
45     - '-t'
46     - '/var/www/html'
47     entrypoint:
48     - 'entrypoint.sh'
49     - 'docker-php-entrypoint'
50
51 volumes:
52     server_rec_db-volume:
53         driver: local
54         driver_opts:
55             type: volume
56             device: /docker/projects/dimis/db
57             o: bind
58
59 networks:
60     default:
61         external: true
62         name: ${NETWORK_NAME}
63
```

```
1 FROM python:3.7-stretch
2
3 COPY requirements.txt /tmp/
4
5 RUN pip install --no-cache-dir -r /tmp/requirements.
  txt
6
7 RUN useradd --create-home appuser
8 WORKDIR /home/appuser
9 USER appuser
10
11 COPY wait-for-it.sh .
12 COPY pika_consumer.py .
13 COPY .env .
14
15 #RUN ./wait-for-it.sh dmis_db:5432 -- python3 -u ./
  pika_consumer.py
16
17 CMD ["python3", "-u", "./pika_consumer.py"]
18
```

```
1 import json
2 import time
3 import zlib
4 from os import environ
5
6 import pika
7 import sqlalchemy
8 from sqlalchemy import Table, Column, MetaData
9 from sqlalchemy import create_engine
10 from sqlalchemy.dialects import postgresql
11 from sqlalchemy.dialects.postgresql import insert
12 from sqlalchemy.exc import IntegrityError
13 from sqlalchemy.types import BIGINT
14
15 global DIMIS_RECORDINGS_DB_PATH
16
17 with open('.env', 'rb') as env_file:
18     environment_variables = env_file.read().split(sep
19 =b"\n")
20     postgres_user = postgres_password = db_name =
21     service_name = None
22     for variable_line in environment_variables:
23         break
24
25 def dict_key_filter(d_in: dict) -> dict:
26     valid_keys = ('DeviceName', 'Unixtime Request', '
27 Unixtime Reply',
28 'Wechselspannung', 'Wechselspannung
29 ', 'Wechselstrom', 'Leistung')
30     d_out = {key: d_in[key] for key in valid_keys}
31     return d_out
32
33 if __name__ == '__main__':
34     # We use an environment variable to configure the
35     consumer-container via docker-compose
36     missing_environ = []
37     expected_environ = ['RABBIT_HOST', 'POSTGRES_USER
38 ', 'POSTGRES_PASSWORD', 'DB_NAME',
39 'DB_CONTAINER_NAME', ']
```

```
35 RABBIT_USER', 'RABBIT_PASSWORD', 'RABBIT_PORT']
36     for element in expected_environ:
37         if element not in environ:
38             missing_environ.append(element)
39
40     if missing_environ.__len__() == 0:
41         rabbit_host = str(environ['RABBIT_HOST'])
42         postgres_user = str(environ['POSTGRES_USER'])
43         postgres_password = str(environ['
44 POSTGRES_PASSWORD'])
45         db_name = str(environ['DB_NAME'])
46         db_host_name = str(environ['DB_CONTAINER_NAME
47 '])
48         rabbit_user = str(environ['RABBIT_USER'])
49         rabbit_password = str(environ['
50 RABBIT_PASSWORD'])
51         rabbit_port = str(environ['RABBIT_PORT'])
52
53     else:
54         print('Missing .env configuration:',
55 missing_environ)
56         exit(10)
57
58     DIMIS_RECORDINGS_DB_PATH = f'postgresql://{
59 postgres_user}:{postgres_password}@{db_host_name}/{
60 db_name}'
61
62     time.sleep(3) # sleep for SQL start
63
64 engine = create_engine(
65     DIMIS_RECORDINGS_DB_PATH,
66     echo=False)
67
68 # noinspection PyUnboundLocalVariable
69 credentials = pika.PlainCredentials(rabbit_user,
70 rabbit_password)
71
72 # noinspection PyUnboundLocalVariable
73 connection = pika.BlockingConnection(
74     pika.ConnectionParameters(host=rabbit_host, port=
75 rabbit_port, credentials=credentials))
76 channel = connection.channel()
```

```

68 channel.queue_declare(queue='task_queue', durable=
    True)
69 channel.basic_qos(prefetch_count=1)
70
71 for method_frame, properties, body in channel.
    consume('task_queue'):
72     body_decompressed = zlib.decompress(body)
73     list_of_dicts = json.loads(body_decompressed,
        encoding='utf-8')
74     print("Tag ", method_frame.delivery_tag,
75           " Received %0.2f kB %03d Messages" % ((len
        (body) / 1024), len(list_of_dicts)), flush=True)
76
77     values_of_device_dict = {} # dict of devicename
        -> list of recorded values of that device
78     list_of_dicts = [dict_key_filter(d) for d in
        list_of_dicts]
79     # Convert Unixtime from seconds[float] to
        milliseconds[int]
80     for d in list_of_dicts:
81         device_name = d['DeviceName']
82         del d['DeviceName']
83         if type(d['Unixtime Request']) == float:
84             d['Unixtime Request'] = int(d['Unixtime
        Request'] * 1000)
85         if type(d['Unixtime Reply']) == float:
86             d['Unixtime Reply'] = int(d['Unixtime
        Reply'] * 1000)
87         try:
88             float(d['Wechselspannung']) # check if
        value is float
89             float(d['Leistung'])
90             float(d['Wechselstrom'])
91             if device_name in values_of_device_dict:
92                 previous_list =
        values_of_device_dict.get(device_name)
93                 list(previous_list).append(d)
94                 values_of_device_dict[device_name
        ] = previous_list
95         else:
96             values_of_device_dict[device_name

```

```

96 ] = [d]
97     except ValueError:
98         print("Not a float, ignored")
99         continue
100
101     metadata = MetaData()
102     recordings_table_dict = {} # dict devicename
    -> sql table objects
103     for recording_device_name in
values_of_device_dict.keys():
104         recordings_table = Table(
recording_device_name, metadata,
105             Column('Unixtime
Request', BIGINT, primary_key=True, autoincrement=
False),
106             Column('Unixtime
Reply', BIGINT, primary_key=True, autoincrement=
False),
107             Column('
Wechselspannung', postgresql.DOUBLE_PRECISION),
108             Column('
Wechselstrom', postgresql.DOUBLE_PRECISION),
109             Column('Leistung',
postgresql.DOUBLE_PRECISION))
110     recordings_table_dict[recording_device_name
] = recordings_table
111
112     metadata.create_all(engine)
113
114     print(f'received recordings for the following
devices: {values_of_device_dict.keys()}')
115
116     for recording_device_name in
recordings_table_dict.keys():
117         try:
118             # https://docs.sqlalchemy.org/en/13/core
/tutorial.html#executing-multiple-statements
119             # runs as SQL-transaction
120             with engine.begin() as connection:
121                 print(
122                     f'Begin insert to table of

```



```

122 device {recording_device_name} with {
    values_of_device_dict[recording_device_name].__len__
    ()} elements')
123         result = connection.execute(
    recordings_table_dict.get(recording_device_name).
    insert(),
124     values_of_device_dict[recording_device_name])
125         assert result
126     except sqlalchemy.exc.IntegrityError as e:
127         print("sqlalchemy.exc.IntegrityError ->
Postgres UPSERT DO_NOTHING")
128         print(e)
129         with engine.begin() as connection:
130             insert_stmt = insert(table=
    recordings_table_dict.get(recording_device_name),
131                                     values=
    values_of_device_dict[recording_device_name])
132             do_nothing_stmt = insert_stmt.
    on_conflict_do_nothing(
133                                     index_elements=['Unixtime
Request', 'Unixtime Reply'])
134             result = connection.execute(
    do_nothing_stmt)
135             assert result
136     except Exception as e:
137         channel.basic_nack(method_frame.
    delivery_tag)
138         raise e
139
140     # Acknowledge the message
141     channel.basic_ack(method_frame.delivery_tag)
142
143 # Cancel the consumer and return any pending
    messages
144     queued_messages = channel.cancel()
145     print('Requeued %i messages' % queued_messages)
146
147 # Close the channel and the connection
148     channel.close()
149     connection.close()

```